SoundLAB

G105DA

4 Channel Stereo
Microphone Mixer

User Manual

Please retain for future reference

IMPORTANT

Installer and Users please note:

These instructions should be read carefully and left with the user of the product for future reference. Before use please inspect the product for any signs of damage. If the product is damaged, DO NOT use it, and contact your supplier immediately.

OPERATING INSTRUCTIONS

The unit can be powered by a 9Vdc power supply (not supplied) or a 9V PP3 battery (not supplied)
To insert a battery, push inwards on the battery cradle (on the right hand side of the unit) and slide up to remove the battery cradle. Insert a 9V PP3 battery making sure to observe the polarity marked on the bottom of the cradle.
Re-insert the battery cradle and slide the catch down to lock the battery compartment.





POWER SWITCH
Press the power switch to turn the mixer on and off.

VOLUME CONTROLS
The volume controls are used to adjust the volume of the 8 input channels.

MODE SELECT
The mode select button is used to select the mode. Pressing in will put the unit into mono mode, releasing the button will put the unit into stereo mode.

MASTER VOLUME CONTROLS
The master volume controls adjust the volume of the 2 master output channels.

OPERATING INSTRUCTIONS



DC INPUT

The unit can be powered by a 9Vdc power supply (not supplied). When purchasing a power supply ensure the diamter of the plug is 5.5mm and the centre hole is 2.1mm diameter. When connecting the power supply make sure to observe the correct polarity (positive outer sheath, negative centre pin).

MASTER OUTPUT CHANNELS

Mode .....Balanced
Connector .....TRS Jack
Rated Output Level.....+4dB/+10dB (max) unbalanced, +10dB/+16dB (max) balanced
Rated Output Impedance.....600Ω, 5K Ω (best) unbalanced, 1.2K Ω, 10K Ω (best) balanced

INPUT CHANNELS

Mode .....Unbalanced
Connector .....TRS Jack
Input Impedance .....≥30K Ω
Rated Input Level .....-10dB

SPECIFICATIONS

Gain 24dB
Frequency Response .....20Hz~20KHz ± 0.5dB, -3dB bandwidth: 10Hz~100KHz
Total Harmonic Distortion.....20Hz~20KHz≤0.05%
Signal To Noise Ratio .....≥80dB (broadband measuring)
Continuous Working Time .....≥12 hours (with 9V PP3 battery)
Dimensions (mm).....152 x 95 x 58

DISPOSAL AND RECYCLING

You must not dispose of this appliance with domestic household waste.
Most local authorities have specific collection system for appliances and disposal is free of charge to the end-user.
When replacing an existing appliance with a similar new appliance your retailer may take the old appliance for disposal.

SERVICE WARRANTY

Electrovision guarantees the product free from defects in materials and workmanship for a period of twelve months.

Should this appliance be operated under conditions other than those recommended, at voltages other than the voltage indicated on the appliance, or any attempts are made to service or modify the appliance, then the warranty will be rendered void.

The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.

Our guarantee is administered by our retailers.

If your product arrives damaged, you must contact the retailer from whom you bought it. The retailer's contact details will be on the invoice that arrived with the product, or on the e-mail you received when you placed the order. Do not contact Electrovision, only your retailer can arrange a replacement.

If the product needs to be repaired or replaced, you must contact the retailer from whom you bought it. The retailer's contact details will be on the invoice that arrived with the product, or on the e-mail you received when you placed the order.

If you have just received your product and require technical help in using it, please call our Help Desk on (0845) 459 4816.

If you have any other technical queries about the product, please call our Help Desk on (0845) 459 4816.

Electrovision Ltd.,
Lancots Lane, Sutton,
St. Helens, Merseyside.
WA9 3EX

www.electrovision.co.uk